

Appendix Q

Groundwater Sampling and Analysis Plan
Revised August 2013
Revised November 2013

**Ameren Missouri Labadie Energy Center
Proposed Utility Waste Landfill
Franklin County, Missouri
Groundwater Sampling and Analysis Plan**

**Ameren Missouri
Power Operation Services
3700 South Lindbergh Blvd.
St. Louis, Missouri 63127**

December 2012
Revised August 2013; Revised November 2013

**GREDELL Engineering Resources, Inc.
1505 East High Street
Jefferson City, Missouri 65101
Phone: (573) 659-9078
Fax: (573) 659-9079**

**Ameren Missouri Labadie Energy Center
Groundwater Sampling and Analysis Plan
Proposed Utility Waste Landfill
Franklin County, Missouri**

December 2012
Revised August 2013; Revised November 2013

Table of Contents

1.0	INTRODUCTION.....	1
2.0	FACILITY LOCATION	2
3.0	FACILITY BACKGROUND	3
4.0	PROPOSED GROUNDWATER MONITORING SYSTEM.....	4
4.1	Well Construction	4
4.2	Well Development or Redevelopment.....	5
5.0	SAMPLING FREQUENCY - DETECTION MONITORING	6
6.0	FIELD SAMPLING EQUIPMENT - QA/QC PROCEDURES	7
7.0	GROUNDWATER SAMPLES - QA/QC PROCEDURES	9
7.1	General.....	9
7.2	Trip Blanks	9
7.3	Field Blanks.....	9
7.4	Equipment Blanks.....	9
7.5	Sample Duplicates.....	9
7.6	Matrix Spikes	10
7.7	Matrix Spike Duplicates	10
8.0	FIELD SAMPLING PROCEDURES.....	11
8.1	General.....	11
8.2	Water Level Measurements.....	11
8.3	Purging.....	11
8.4	Sampling	13
9.0	SAMPLE TRANSPORT AND DELIVERY, CHAIN-OF-CUSTODY	14
10.0	ANALYTICAL LABORATORY - REPORTING AND QA/QC PROCEDURES	16
10.1	Accuracy.....	16
10.2	Precision.....	16
10.3	Completeness.....	16
10.4	Reporting Requirements.....	17
11.0	STATISTICAL ANALYSIS	19
11.1	Characterization of Well Network and Selection of Statistics	19
11.2	Prediction Intervals or Other Statistical Tools	19
11.3	Choice of Statistical Test for Limited Data	19
11.4	Non-Detects	20
11.5	Normality Testing.....	20
11.6	Outlier Testing	20
11.7	Prediction Interval Testing	22
11.8	Procedures for Response to Future SSI's.....	22
11.9	Current MDNR Protocols	25
12.0	REFERENCES	26

List of Figures

Figure 1 – Site Location Map

Figure 2 – Monitoring Well Location Map

Figure 3 – Typical Groundwater Monitoring Well Construction Detail

List of Tables

Table 1 – Groundwater Monitoring Well Information Summary

Table 2 – Groundwater Monitoring Schedule

List of Appendices

Appendix 1 Driller's Logs and Monitoring Well Construction Details

Appendix 2 Missouri Solid Waste Management Rule – Constituents for Detection Monitoring (10 CSR 80-11.010, Appendix I)

Appendix 3 Field Equipment Calibration Forms and Procedures

Appendix 4 Sample Container and Preservation Guidelines and Groundwater Sampling Bottle Inventory Form

Appendix 5 Monitoring Well Field Inspection Form

Appendix 6 Field Sampling Log and Volume Tracking Log Forms

Appendix 7 Example Chain-of-Custody Field Record Form

Appendix 8 Decision Flow Charts

1.0 INTRODUCTION

This sampling and analysis plan (SAP) has been prepared by GREDELL Engineering Resources, Inc. for the proposed Ameren Missouri Labadie Utility Waste Landfill, located adjacent to the Labadie Energy Center and approximately two and one-half miles northeast of the town of Labadie and immediately southeast of the Missouri River in northeast Franklin County, Missouri. The proposed utility waste disposal area and surrounding areas to the north, south, and east are currently used primarily for agricultural (row-crop) production. The Labadie Energy Center is located immediately to the west. Labadie Bottom Road marks the approximate western boundary of the site and Davis Road marks the eastern boundary of the site. The general location is shown on Figure 1.

The SAP has been prepared consistent with the rules and regulations promulgated by the Missouri Department of Natural Resources Solid Waste Management Program (SWMP) and the Division of Geology and Land Survey (DGLS), found under 10 CSR 80-11.010(11)(C)2. through 10 CSR 80-11.010(11)(C)6. and 10 CSR 23-4, respectively. This SAP includes the following information: QA/QC procedures to be followed during both field sampling and laboratory analyses; groundwater sample preservation and shipment procedures; a chain-of-custody procedure; and discussion of statistical methods to be followed in the evaluation of groundwater samples gathered in accordance with this plan. Site-specific technical reports were also consulted during development of this plan. They include:

Detailed Site Investigation Report for Ameren Missouri Labadie Power Plant Proposed Utility Waste Disposal Area, Franklin County, Missouri, dated February 4, 2011, revised March 30, 2011 by GREDELL Engineering Resources, Inc. and Reitz & Jens, Inc.

Construction Permit Application for Utility Waste Landfill, Ameren Missouri Labadie Energy Center, prepared by Reitz & Jens, Inc. and GREDELL Engineering Resources, Inc.

This SAP is being submitted as an appendix to the solid waste disposal area construction permit application referenced above. The SAP focuses on the implementation of appropriate sampling and analysis procedures for the establishment of a groundwater detection monitoring system at the proposed utility waste landfill. This SAP will help ensure that the landfill development proceeds in an environmentally sound fashion, consistent with Solid Waste Management Law and Rules.

2.0 FACILITY LOCATION

The proposed Labadie UWL is located within the alluvial floodplain of the Missouri River in northeastern Franklin County approximately two and one-half miles northeast of the town of Labadie and six miles north of intersection of State Hwy 100 and Interstate 44 (Figure 1). The National Geodetic Survey indicates the site lies within the northwestern part of Township 44 North, Range 2 East. Portions of the area are part of the “historic” Spanish Land Grant survey system identified as “SUR”. The site is located within sections 17 and 20, SUR 384, and SUR 1735. The site has had a historical land use of agriculture.

Groundwater levels are largely influenced by fluctuations in Missouri River level. Depth to groundwater is relatively shallow and varies from two to 13 feet, but levels were noted in some instances to rise up to, and during infrequent high-river stages, may slightly exceed ground surface elevation. Hydraulic gradients are also shallow. Minimum values range from 1.990×10^{-6} ft/ft to 6.161×10^{-5} ft/ft (0.015 to 0.33 ft/mi). Maximum values range from 3.517×10^{-3} ft/ft to 5.534×10^{-4} ft/ft (3 to 18 ft/mi). Calculated hydraulic conductivity values range from 9.47×10^{-2} to 2.15×10^{-2} feet per minute (ft/min), and average 4.91×10^{-2} ft/min. These values fall within the range of hydraulic conductivity values typically ascribed to coarse and medium sand deposits.

3.0 FACILITY BACKGROUND

The Ameren Missouri Labadie Utility Waste Landfill is being proposed as a landfill site to accommodate the waste generated from the flue gas desulfurization units, fly ash, and bottom ash.

The proposed UWL covers a waste boundary area of approximately 166.5 acres of the 813-acre landfill permit boundary within the Ameren Missouri Labadie Energy Center Property. The entire site is zoned by Franklin County as Agricultural Non-Urban (ANU). Improvements within the Labadie UWL permit boundary include the 166.5-acre waste disposal area, stormwater management ponds permitted separately as no discharge wastewater facilities under Missouri Clean Water Law, soil stockpile areas, flood protection berms, perimeter stormwater control structures, site access roads, perimeter security fencing, buffer zones, and groundwater monitoring.

In order to ensure that groundwater is protected a series of groundwater monitoring wells are proposed for installation both upgradient and downgradient of the UWL. Periodic sampling of the groundwater monitoring well system is required under Missouri's Solid Waste Management Regulations, 10 CSR 80-11.010(11).

4.0 PROPOSED GROUNDWATER MONITORING SYSTEM

The proposed groundwater monitoring system consists of 35 permanent wells and one temporary well (Figure 2). Thirty-three wells (MW-1 through MW-32, and temporary monitoring well TMW-1) will monitor shallow groundwater contained within the unconfined alluvial aquifer that underlies the site as recommended in the Detailed Site Investigation. Three deep wells [MW-33(D), MW-34(D), and MW-35(D)] will monitor deeper zones within the unconfined alluvial aquifer. The wells that generally are downgradient from waste disposal boundaries are designated MW-1 through MW-21, MW-28 through MW-32, MW-33(D) and MW-34(D). The wells that generally are upgradient from waste disposal boundaries are designated MW-22 through MW-28, and MW-35(D). Individual well location and depth information is summarized in Table 1. The table also lists the temporary monitoring well (TMW-1) that will serve as a "sentry" for the initial operations within Cell 1. It will be used to supplement water quality data derived from the permanent downgradient wells located along the eastern perimeter of Cell 3.

Justification for the location of the proposed permanent well system is presented in Appendix X of the Construction Permit application. The proposed wells will be installed prior to acceptance of waste. TMW-1 will be removed when Cell 3 becomes operational.

4.1 Well Construction

All monitoring well drilling and construction will be completed in accordance with the Missouri Monitoring Well Construction Code of regulations found in 10 CSR 23-4. A typical monitoring well construction detail for the proposed well installation is provided as Figure 3. Well depths will be in general accordance with Table 1 to ensure full submersion of each 10-ft screen interval. Some allowances may have to be made in actual well location to ensure they do not conflict with planned landfill development, terrain or subsurface irregularities, overhead power lines, or similar encumbrances. This in turn will affect actual well depths, which are based on ground surface elevations.

Drilling and well construction will be completed by a properly permitted monitoring well installation contractor. Drilling logs and monitoring well construction details will be completed subsequent to installation activities and inserted into Appendix 1 of this SAP at a later date.

Proposed monitoring wells will be located such that reasonable access can be gained for the purpose of maintenance and repairs. The surrounding natural drainage will not be impaired. Each well will be placed so as to facilitate surface water drainage surrounding the well.

4.2 Well Development or Redevelopment

Each well will be developed with the use of either disposal bailers or a non-dedicated, submersible pump. In no event will the method used introduce any contaminants into the wells. A minimum of three well volumes of water will be removed or until the well is effectively "dry". A "well volume" includes both the filter pack and casing, as measured from the base of the well to the initial static water level. In addition, the volume of potable water introduced into the well bore while drilling and/or constructing the well, if any, will be removed.

Field measurements of groundwater temperature, pH, and specific conductivity will be recorded during the development process. Field measurements will continue until both temperature and specific conductivity have stabilized to within ten percent between three successive readings. Similarly, pH readings should stabilize within 0.2 pH units.

In addition to the above, development records will include documentation of both pre- and post-development water levels. Final clarity of the water will also be noted.

Redevelopment will be undertaken when 20 percent of the well screen is occluded by sediments, as determined during routine measurements of the depth of the well taken during field sampling events.

5.0 SAMPLING FREQUENCY - DETECTION MONITORING

Detection monitoring is required at all monitoring wells. The sampling frequency required by 10 CSR 80-11.010(11)(C) is twice yearly during the months of May and November, except for initial background water quality monitoring following well installation and prior to operation. The rule requires a minimum of four independent samples to be collected from each well. This requirement allows identification of background concentrations contained in the alluvial aquifer using a statistically valid number of sampling events. Background water quality data are critical to identify in order to allow comparison with subsequent sample analysis to determine if statistically significant increases in target contaminants are present within the groundwater.

The proposed schedule for background water quality sampling at the Ameren Missouri Labadie Utility Waste Landfill is presented in Table 2. The intent of the schedule is to provide eight independent rounds of background data prior to the start of operations. The eight sets of data (from the four minimum sampling events required by the rule plus four additional sampling events) will better define the spatial variability of groundwater quality across the footprint of the disposal area. The degree of spatial variability will ultimately determine the statistical approach to be used in the evaluation of detection monitoring results. Sampling events will also be scheduled such that they occur no sooner than twenty-four (24) hours after cessation of pumping from the irrigation well located approximately 1,800 feet northeast of proposed waste boundaries (see Plan Sheet 4 of CPA drawings).

Detection Monitoring will include analysis of the parameters listed in Appendix I of 10 CSR 80-11.010. Those parameters are listed for reference in Appendix 2.

6.0 FIELD SAMPLING EQUIPMENT - QA/QC PROCEDURES

All field personnel must read and familiarize themselves with the protocol established in this section. All personnel involved in the sampling process must wear Level D Protective clothing as defined by OSHA. This includes, but is not limited to, safety boots/shoes, safety glasses, and disposable gloves. No smoking is allowed during sampling. A first aid kit must be accessible to field personnel during each well sampling event.

The following equipment, at a minimum, will be available in the field during each sampling event: purging and sampling equipment, both dedicated and non-dedicated; an electronic water level measurement device; pH, temperature, specific conductivity, oxidation-reduction potential (ORP), and turbidity meters; sample containers, and coolers.

The probes and attachments of each pH, temperature, specific conductivity, oxidation-reduction potential (ORP), and turbidity meter will be triple rinsed in distilled water. The meters will then be calibrated in accordance with manufacturer's recommendations or as otherwise specified in the *Field Equipment Calibration Forms and Procedures* included in Appendix 3. Any malfunction will be corrected or the meter will be replaced.

Sample containers will be pre-cleaned by the contract laboratory by washing in a laboratory grade, non-phosphate detergent, triple rinsed in distilled water, and sufficiently dried to remove all moisture. The sample containers will be checked/inventoried for proper container volume, material, preservatives, labels and any observed defects (e.g., preservative leakage) at the time of receipt from the laboratory and documented on the *Groundwater Sampling Bottle Inventory* form (Appendix 4).

Prior to collecting a sample, the following decontamination procedures will be implemented.

1. Purging and Sampling Equipment will be handled and decontaminated as necessary to prevent contamination of the wells.
 - a. If non-dedicated purging and sampling equipment is used, it will be thoroughly decontaminated and tested by collecting an equipment blank prior to use (see Section 7.4 Equipment Blank).
 - b. If disposable bailers are used in the purging and sampling of the wells, they will be new, single-use bailers for each well and purging/sampling event. Used disposable bailers, even if decontaminated, are not acceptable.
 - c. If dedicated pumps or bailers are used, care will be taken to prevent cross contamination.

2. Water level measuring device, including sensor probe and the entire length of graduated tape will be washed in laboratory grade, non-phosphate detergent followed by a triple rinse in distilled water.
 - a. As the tape is reeled back onto the carrying spool, it will be wiped and dried using clean, dry paper towels.
3. During sampling, carefully lower the purging and sampling equipment into the well, handling it only with clean, disposable gloves. Do not drop any equipment into the well. The intake of the sampling equipment should be suspended above the base of the well to avoid churning of particulate matter within the sump.
4. After each well is sampled or during sampling events, as necessary, disposable gloves should be discarded, hands washed with soap and water, and fresh disposable gloves applied before the next sampling.
5. After use, the purging and sampling equipment will be washed in laboratory grade, non-phosphate detergent, followed by a triple rinse with distilled water, prior to any further use.
6. Should purging and sampling equipment malfunction or not be available for use during the sampling event, substitute equipment or a bailer may be used.
7. All handling of the bailer will be with clean disposable gloves. Gloves must be changed as often as necessary, particularly if contact is made with other substances during the bailing process. The bailer must not be allowed to contact any foreign substance, in which case the bailer will be promptly replaced, regardless of condition.
8. Lightweight, high tensile strength line or a similar product used in conjunction with the disposable bailers or reel systems will be discarded and replaced each time a well is sampled.

If dedicated pumps are used, care should be taken to prevent any foreign objects from being part of the sample. The outside of the sample discharge tubing should be cleaned to prevent introduction of foreign objects into the sample container.

7.0 GROUNDWATER SAMPLES - QA/QC PROCEDURES

7.1 General

Precautions must be taken during both sampling and shipping procedures to ensure representative groundwater is obtained. Sample blanks and sample duplicates are therefore required to guard against and/or identify accidental, "induced" contamination from these sources. Sample blanks include trip blanks, field blanks, and equipment blanks. Sample duplicates are self-explanatory, but can include both matrix spike and matrix spike duplicates. Each of these quality control features is explained more fully as follows.

7.2 Trip Blanks

Trip blanks are prepared in the laboratory. They are designed to detect contamination resulting from improper or inadequately cleaned containers, sample coolers used for transport, or from chemical preservatives. A trip blank is prepared by filling an appropriately sized container with distilled water and any applicable chemical preservative. It is then shipped with the sample containers from the laboratory and subsequently accompanies groundwater samples on the "trip" back to the laboratory. Trip blanks must be clearly identified as such along with the analyses to be performed on them. At a minimum, one trip blank per sampling event will be provided.

7.3 Field Blanks

Field blanks are prepared in the field. A field blank is prepared by directly filling an appropriately sized container with laboratory-supplied deionized water. Field blanks are used to detect contamination resulting from changed ambient air conditions. They also serve as a check against trip blanks. Field blanks should be clearly identified in the sampler's field notes and appropriately labeled to ensure its later identification in laboratory analytical results. One field blank will be collected per sampling event.

7.4 Equipment Blanks

Equipment blanks are prepared in the field when non-dedicated sampling equipment is used. They are used to ensure that non-dedicated equipment is properly decontaminated. This is accomplished by collecting a sample of distilled water passed through non-dedicated equipment after they have been decontaminated. Equipment blanks should also be collected anytime new, dedicated equipment is introduced into the water sampling process. Equipment blanks should be clearly identified in the sampler's field notes and appropriately labeled to ensure its later identification in laboratory analytical results. At a minimum, one equipment blank per sampling event will be collected.

7.5 Sample Duplicates

Sample duplicates are independent samples collected as close in time as possible as the original sample from any given well. They are stored and analyzed separately from the original sample and are a check on the precision of the sampling and analytical process.

Sample duplicates must immediately follow original sample collection of any given chemical parameter. Because they serve as a check on the reproducibility of data generated by the analytical laboratory, labeling should follow a format that does not overtly divulge the true identity of the sample on the sample labels or on the chain-of-custody sheet. It should be clearly identified in the sampler's field notes and appropriately labeled to ensure its later identification in laboratory analytical results. One sample duplicate will be collected for every 20 samples. At a minimum, one sample duplicate per day per sampling event will be collected.

7.6 Matrix Spikes

Matrix spikes are prepared in the laboratory by adding a known amount of target analyte to a sample prior to preparation and analysis. They are used to determine the bias of a method in a given sample matrix.

7.7 Matrix Spike Duplicates

Matrix spike duplicates are intra-laboratory split samples containing identical concentrations of target analytes. They are used to substantiate matrix spike samples.

8.0 FIELD SAMPLING PROCEDURES

8.1 General

Upon arrival at each monitoring well, its physical condition must be documented. Appendix 5 contains a *Monitoring Well Field Inspection* form that must be filled out for each well each time it is sampled. Any irregularities in the condition of the well must be immediately reported and corrective action implemented prior to the next sampling event.

8.2 Water Level Measurements

The next procedure is to obtain water level measurements. They must be obtained immediately prior to any attempt to purge the well. All water levels measuring equipment will be thoroughly decontaminated as previously described and checked for wear and abrasion prior to use. Clean, disposable gloves will be worn. All measurements must be recorded to ± 0.01 foot and should be based on a permanent reference point located at the top of the well, the elevation of which is established by a licensed surveyor.

Once the sample is collected, it is also necessary to measure the depth of the well. This is required to determine if the well screen is partially blocked by sediment, thus inhibiting recharge. If accumulated sediment obstructs more than twenty percent of the well screen height, it will be reported and arrangements made to redevelop the well prior to the next sampling event. Record all data gathered during water level measurements on the *Field Sampling Log* form provided in Appendix 6.

Ensure the well cap is clean prior to replacing after measurements are complete. Do not leave the well cap off for any reason, even for brief periods, unless purging immediately commences.

8.3 Purging

The next procedure is to purge the wells. There are two potential methods for purging the wells: Purge/Recover Sampling method; and Low-Flow Sampling method. Each method is acceptable, if the procedures are diligently followed. Each method is described separately below. All purge volumes must be documented on the *Volume Tracking Log* form provided in Appendix 6.

Purge/Recover Sampling: If using dedicated purge and sampling equipment, the following paragraph does not apply. If non-dedicated purge and sampling equipment is used, the wells should be purged in an order that precludes any potential cross-contamination. Typically, the upgradient wells are purged prior to the downgradient wells.

Purging must occur prior to any sampling, because water standing in the well may be unrepresentative due to physical and/or chemical alteration. Each well will be purged by removing at least three well volumes of water or until purge parameters stabilize. A well

volume is considered the sum of the saturated portion of the well casing plus the saturated portion of the filter pack, which is roughly equivalent to an effective pore volume of 30 percent. The calculated volumes are based on the height of the water column above the established base of the well as measured immediately prior to purging. Filter pack heights must also be known. Well construction information for this facility will be placed in Appendix 1 following construction of the wells.

Wells will be purged using either dedicated bailers or other suitable purging and sampling equipment. All handling of purging equipment will be done wearing clean disposable gloves. Purge water will be poured into a graduated container sufficient to allow accurate measurement of the volume of water obtained. Once a well volume is obtained, temperature, specific conductivity, pH, oxidation-reduction potential (ORP) and turbidity will be recorded. Temperature must be measured first, followed by specific conductance ORP, pH, and lastly by turbidity. It is important to measure specific conductance and ORP prior to pH due to the potential presence of salts on the pH probe unit. All meters will be calibrated and checked for proper operation following manufacturer's recommendations or as otherwise outlined in Appendix 3. The clarity (turbidity) of the water will be noted. Cloudy, turbid water must be minimized.

Low-Flow Sampling Method: When using dedicated low flow pumps and automatic purge parameter sensors, such as the YSI 5083 Flow Cell, the following procedures will be followed to assess the stability of a water sample. At a minimum, all water will be purged from the line between the low-flow pump and the automatic sensors. This will be done by allowing a minimum of one volume within the connecting sampling tubing to flow from the well before assessing the stability of the water sample.

To be considered stable, the reading from each respective purge parameter sensor will be compared to the previous two values (collected at least one minute apart), and will be within the following limits:

- | | |
|---------------------------------|----------------------|
| • pH | +/- 0.2 S.U. |
| • Specific Conductance | +/- 20 umhos/cm |
| • Temperature | +/- 1 C |
| • Oxidation-Reduction Potential | +/- 20 millivolts |
| • Turbidity | +/- 1 NTU (optional) |
- or
- | |
|---|
| • 10 percent for SC, temperature, ORP and turbidity and +/- 0.2 S.U. for pH |
|---|

If one-quarter inch ($\frac{1}{4}$ ") tubing is used to connect the low flow pump to the automatic sensor, it takes one minute to purge 26 feet of tubing at 250 ml/minute.

Once sampling is complete, properly dispose of all purge water. Record all purge data on the *Field Sampling Log* form provided in Appendix 6.

8.4 Sampling

The next procedure is the actual sampling of the well. As much as practical, sampling should take place within two hours of the final purge event. In some instances, the recharge characteristics of the screened interval may be such that the two-hour stipulation is not feasible. In that event, sampling should be performed no later than 24 hours after final purging. Wells should be sampled in the order that precludes as much, to the extent practical, any potential cross-contamination. Typically, the upgradient wells are purged prior to the downgradient wells. Samples from each well will be collected in the following order, based on their sensitivity to volatilization:

- TOX
- TOC
- TDS
- Metals
- Non-metals
- COD

Samples must be carefully decanted into the appropriate sample container. Agitation must be minimized to avoid altering the chemical makeup of the sample. If well pumps are being used, care should be taken to prevent any contaminant from the exterior of the sample tubing from contaminating the water sample. Field filtration of samples is not allowed under 10 CSR 80-11.010(11)(C)2.B. Consequently, sample clarity must be documented and efforts made to minimize increasing turbidity beyond what naturally occurs in the well environment. Once a sample is retrieved, it will be preserved according to the guideline provided in Appendix 4. Samples requiring storage at low temperature will be immediately placed in coolers packed with ice. The temperature of the storage coolers will be monitored to ensure appropriate temperatures are maintained. All sampling data will be documented on the *Field Sampling Log* form provided in Appendix 6.

9.0 SAMPLE TRANSPORT AND DELIVERY, CHAIN-OF-CUSTODY

A chain-of-custody procedure is necessary to ensure the integrity of samples from the time of collection through delivery and final analysis. A sample is considered in someone's custody if:

1. It is in that person's physical possession;
2. In view of that person once he/she has taken possession;
3. Has been secured by that person so as to prevent tampering, or;
4. Has been placed by that person in an area restricted to authorized personnel.

Any person with custody as defined above must comply with the procedures established herein.

Prior to transport, the person collecting the samples must properly label each sample container and complete a *Chain-of-Custody Field Record* form. An example chain-of-custody field record form is provided in Appendix 7. Each label must be secured to the container and the following information clearly described on the label in indelible marker or pen:

- Collector's name
- Date and time of sampling
- Monitoring Well ID
- Sample ID
- Preservative(s) used, if any
- Required analytical test(s)

If the sample cooler(s) used for transport is not tamper proof, each sample container must also have a tamper proof seal affixed by the collector across the lid. A chain-of-custody summarizing the samples to be transported is also required. This form should be prepared by the collector and completed upon final sampling. A copy of the form(s) should accompany the person responsible for transporting the samples so that it can be included with the final analytical report as support documentation. The sample collector also initializes the chain-of-custody record process. It is his/her responsibility to ensure that the record is maintained upon relinquishment of the samples for transport to the laboratory.

When samples are transported, the carrier assumes responsibility for the chain-of-custody record and for ensuring safe transport of the samples to the laboratory. The carrier must recognize the contents of the shipment, the potential hazards they entail, and demonstrate an understanding of the proper handling precautions to be used during transport. The carrier is responsible for ensuring that all samples are properly stored to avoid leakage or breakage. Sample coolers should be checked to ensure required temperatures are

maintained and any additional ice is added as necessary. Do not use dry ice during transport. The carrier must also ensure that all relevant shipping manifests are properly and fully completed. Other individuals who might accompany the carrier must be advised of the nature of the shipment and must not be allowed direct contact with any of the samples.

Any transfer of samples from one carrier to another must be accompanied by the chain-of-custody record and the above process repeated prior to relinquishment of the samples. The carrier must deliver the samples to the laboratory as soon as practicable after sampling, generally no later than 48 hours. The carrier should ensure that the samples are delivered to the person in the laboratory qualified to receive samples prior to relinquishment of the chain-of-custody record to that individual.

The laboratory should assign a specific individual to be responsible for the samples. This individual should first inspect the condition of the sample containers and any seals, and then reconcile the information on sample labels with that listed on the chain-of-custody record prior to signing the record. This individual should then assign laboratory numbers to each sample, enter these numbers on the laboratory logbook and on each sample container label, and should store the samples in a secured storage area until ready for analysis. This individual is ultimately responsible for completion of the chain-of-custody record and for ensuring that it forms part of the final analytical report.

10.0 ANALYTICAL LABORATORY - REPORTING AND QA/QC PROCEDURES

The contract laboratory must have the ability to produce reliable quantitative results in accordance with established protocol. At a minimum, the laboratory must use analytical methods that will achieve the nominal target reporting limits for the MDNR Appendix I groundwater monitoring parameters listed in Appendix 2. Adequate levels of accuracy, precision, and completeness must be maintained.

10.1 Accuracy

Accuracy is defined as the degree of agreement between the measured amount of a species and the amount actually known to be present, expressed as a percentage. To achieve an adequate appraisal of accuracy, spikes and/or control samples should be made for one of every twenty samples analyzed. Minimum levels for accuracy should be listed in specific laboratory quality assurance plans.

10.2 Precision

Precision is a measure of the reproducibility of analytical results, generally expressed as a *Relative Percent Difference*. To achieve an adequate appraisal of precision, duplicate analyses should be performed for every one in twenty samples. Minimum levels for precision should be listed in specific laboratory quality assurance plans.

The relative standard deviation is a measure of the variability of the results from an analytical procedure. The relative standard deviation is calculated by taking the difference between a sample result, x , and the average of sample results from numerous laboratories, $x_{\bar{}}^{}_{}$, for each analyte divided by $x_{\bar{}}^{}_{}$ [$(x-x_{\bar{}}^{})/x_{\bar{}}^{}_{}$ expressed as a percentage].

The relative percent difference is the difference, by analyte, between the results of duplicate sample divided by the average value for those samples [$(x_1-x_2)/((x_1+x_2)/2)$ expressed as a percentage]. It is a measure of the variation in the results of an analyte for duplicate samples.

If the results for duplicate samples of an analyte for relative percent difference are within 2.5 times the percent relative standard deviation, the analytical data for the parameter may be accepted as being comparable results. If the results of an analyte for duplicate samples for relative percent difference are not within 2.5 times the percent relative standard deviation, the results of the analyte should be checked for comparability.

10.3 Completeness

Completeness is a comparison of the amount of valid data acquired to the amount of valid data planned to be obtained, expressed as a percentage. Should the percentage of completeness fall below 90 percent for the analytical results of any given sampling event,

the laboratory should be prepared to present a corrective action narrative prior to receiving further groundwater samples.

10.4 Reporting Requirements

Minimum reporting requirements for the laboratory responsible for analytical results of groundwater monitoring well samples are as follows:

1. A table summary of all analytical test methods used in the analysis, including references for each to the method manual and test method number.
2. A summary of all analytical results. This must include use of appropriate units, reporting Practical Quantitation Limit (PQL), and appropriate signature on all data sheets. Units must be shown for each analyte. Data cannot be method blank corrected. Data must be appropriately flagged.
3. A complete chain-of-custody form(s). A complete form includes name and affiliation of sample collector, time and date of sampling, and all appropriate signatures denoting custody changes. The chain-of-custody form should be an original or a highly legible copy.
4. A completed copy of the field sampling log(s) contained in Appendix 6 of this Sampling and Analysis Plan.
5. Method detection limits must be established for all metals analysis. Method blank results are required.
6. All inorganic results will be accompanied by a Quality Assurance data form that includes minimum detection limits, method blanks, field or trip blanks, and lab replicate. If spiked samples are used, these data will also be included.

Supplemental laboratory data will include a summary that chronicles laboratory procedures, including date of sampling, sample receipt, preservation, preparation, analysis, and approval signature of the results.

Upon the initiation of routine semi-annual detection monitoring and once laboratory analytical data are received, facility personnel must in turn submit the data to MDNR-SWMP in report form for review and comment within 90 days of the date of sampling. Information to be contained in the report should include the following:

1. Clearly state the purpose of the submittal (i.e. either detection or assessment monitoring).

2. Supply a copy of field notes, including all field data sheets.
3. Provide unaltered copies of the “raw” analytical data. A summary table is also recommended, but cannot take the place of the “raw” data.
4. Include the completed chain-of-custody form(s).
5. Summarize the data validation procedures.
6. Summarize groundwater flow direction and hydraulic gradient. Compare and contrast with previous data. Supply an updated water table (potentiometric) map prepared by a properly qualified individual.
7. Provide a statistical analysis summary using approved methods, including discussion of any statistically significant increase over established background values.
8. Note any deviations from the Sampling and Analysis Plan that may have taken place during the sampling event.
9. Provide electronic submission of groundwater data in a format and method prescribed by the MDNR-SWMP.

11.0 STATISTICAL ANALYSIS

The statistical analysis procedure(s) used for the Ameren Missouri Labadie Utility Waste Landfill (UWL) were selected to be consistent with the requirements of 10 CSR 80-11.010(11)(C)5. The statistical analysis plan below was developed for this facility and is submitted for review and approval.

This section contains a general discussion of the type of statistics chosen for the facility. The type of statistics chosen reflects the understanding that the site is located in a flood plain, and the shallow alluvial groundwater will be monitored.

11.1 Characterization of Well Network and Selection of Statistics

Upon installation of permanent groundwater monitoring wells, the Labadie Energy Center will follow the schedule for sampling shown in Table 2. After eight rounds of background sampling, a report will be prepared comparing the distribution of data for each parameter in both the upgradient and downgradient wells. Comparisons may include Box Plots for median, quartile and extreme values and Kruskal Wallis tests for comparison of populations at a 0.05 level of significance or other tests as appropriate. If downgradient well data are not comparable to upgradient well data, intra-well statistics will be considered for future comparisons. If data from one or more upgradient wells are comparable to the downgradient well(s) data, inter-well statistics will be considered for future comparisons.

11.2 Prediction Intervals or Other Statistical Tools

Parametric and non-parametric prediction intervals will be used as discussed below. The types of statistics to be used include parametric and non-parametric prediction intervals. For intra-well comparisons, the parametric and non-parametric prediction intervals will be defined by the data from previous samples collected at the well being reviewed. For inter-well comparisons, the parametric and non-parametric prediction intervals will be defined by the data from previous samples collected at the upgradient well(s).

Below is a specific discussion on the implementation for the statistics listed above. Prediction intervals for parametric and non-parametric distributions are recommended. Most computer statistical software programs include distribution testing with the appropriate selection of normal, log normal or non-parametric distribution. Some statistical software programs use the Ladder of Powers concept in an attempt to normalize data. Prediction intervals may include samples with results below detection limits by using either the Cohen or Aitchison approximations for a limited number of non-detects.

11.3 Choice of Statistical Test for Limited Data

The following restrictions apply to these statistical methods recommended in Section 11.2 depending on the number of samples that have been collected:

- Sample size < 4 – do not run statistics
- Sample size ≥ 4 but ≤ 8 – may use Poisson Prediction Limit Test or similar tests as a cursory review of parameter concentrations. Elevated parameters from this test are not Statistically Significant Increases (SSIs), but are parameters that will need to be looked at more closely when the sample size is greater than 12
- Sample size > 8 – use recommended Statistical methods

11.4 Non-Detects

There are limitations on the use of statistical procedures if analytical results do not detect a parameter. Examples are as follows:

- For non-detects ≥ 76 percent and < 100 percent, use a non-parametric inter-well prediction interval testing with the Upper Prediction Limit (UPL) = to the largest non-outlier value.
- For non-detects equal to 100 percent, use a non-parametric prediction interval testing with the Upper Prediction Limit (UPL) = the Practical Quantitation Limit (PQL). The analytical laboratory will maintain the lowest PQL practicable. Significant changes in PQL (± 25 percent) will be avoided as much as practicable.
- For non-detects < 25 percent, use PQL divided by two, or Cohen's Adjustment, and check for normality. The SWMP may approve use of a median PQL.
- For non-detects ≥ 25 percent and < 75 percent, use Cohen's Adjustment or a modified Aitchison's Adjustment (also known as the modified delta method), and check for normality.

11.5 Normality Testing

The purpose of normality testing is to determine whether the background data is normally distributed or if it can be normalized through transformation. Data that is normally distributed or that can be normalized will be evaluated using a parametric statistical tool. Data that is not normal will be evaluated using a non-parametric statistical tool. Examples of normality testing include:

- For sample population ≤ 50 – Shapiro-Wilk Test or equivalent
- For sample population > 50 – Shapiro-Francia Test or equivalent

Show normality testing on at least the original data, data residuals, and natural logarithmically transformed data or data transformed by the Ladder of Powers concept.

11.6 Outlier Testing

Since most of the software packages available use either the t-test or Dixon's method for determining outliers and neither of these methods can determine multiple outliers the SWMP has developed the following procedure to be used in determining outliers.

Screen data first by using Probability Plots and Time Series Plots. The Time Series Plot and the Probability Plots will aid in determining whether there are multiple possible outliers or a single possible outlier. The time Series Plot is used along with the Probability Plots to screen for possible outliers, a screening tool. The possible outliers are the points on the Probability Plots that appear out of alignment with the rest of the data. Care should be taken when using Probability Plots because non-normal data will also have points out of alignment as compared to the rest of the data. In addition, the Probability Plots will help determine if the numerical tests should be evaluated using log-transformations or transformed by the Ladder of Powers concept.

Determine the Median value for the Data to be processed. The median was chosen because the median value is not changed by either high or low values. This value is the *screening tool* to be used in the steps listed below:

- Use the screening tool to determine what values are possible outliers. The Time Series Plots could aid in the identification. If the number of possible outliers is equal to one, run the outlier test on that one value. If there are no possible outliers identified, do not screen for outliers. If there is more than one possible outlier proceed to the next step.
- Determine if one or more of the possible outliers could mask the other outliers. For example, for possible outlier values of 194, 290, 332, 838 and 1630, 1630 could mask 838 as an outlier. When masking can occur, each possible outlier should be tested with the other possible outliers not used in the calculations. In the example given, tag the value of 1630 and then run the outlier test on the value of 838. If the value 838 is an outlier then the value 1630 would also be an outlier and removed from the data set as confirmed outlier.
- If the outlier test would be run on the complete data set of 194, 290, 332, 838 and 1630, to determine if 1630 was an outlier, the value of 838 would not be an outlier if the value 1630 were not an outlier.

Also, when looking at the initial sample values, use the time series plots to determine if these initial values are within reasonable limits as compared to the other early samples. Some parameters have high readings the first few times a well is tested and these higher readings could mask a trend if they are not removed early in the monitoring program. Simply relying on a computer program to determine outliers without looking at the data through a visual means can give erroneous results.

There are different outlier tests depending on the number of samples:

- Use only Dixon's Test if the sample size is ≤ 25 .

- Use Rosner's Test, if available, only if the sample size is ≥ 20 . Rosner's Test is able to test for either single or for multiple outliers. Although Rosner's test avoids the problem of masking when multiple outliers are present in the same data set, it is not immune to the related problem of *swamping*. Swamping refers to a block of measurements all being labeled as outliers even though only some of the observations are actually outliers. This potential pitfall seems to be in properly identifying the total number of possible outliers. Following the screening procedure above should minimize the problem of *swamping*:
 - Outliers can only be excluded for the analytical event in which they are determined.
 - Previously determined outlier results will be re-checked when background is updated to confirm that these results are still outliers and not included in the background database.
 - Last date outliers of compliance well comparisons must not be excluded from current analysis.
 - Outlier screening will never be applied to the current (future values) monitoring data of control charts.

Other types of outlier test, besides those mentioned previously, may be used.

11.7 Prediction Interval Testing

When inter-well comparisons are being used, compare inter-well Upper Prediction Limit (UPL) to each downgradient well's last date value. Inter-well UPL is calculated from all dates of upgradient well background data.

When using intra-well comparisons, compare the UPL from previous sampling to the results by constituent of the current round of sampling results by constituent.

11.8 Procedures for Response to Future SSI's

This section contains a general discussion on the re-sampling strategy for any parametric or non-parametric inter-well prediction interval methods, re-sampling used to verify SSI's. An SSI is not proven:

- If the pooled background sample size (n) is ≤ 10 , there is one resample out of two samples that does not show an SSI for the parameter; or

- If the pooled background sample size (n) is > 10, the single resample does not show an SSI for the parameter

This sampling strategy is identified in flow charts provided in Appendix 8.

If an SSI is confirmed, current (1997) Missouri Solid Waste Management Rules require the following procedures [Reference 10 CSR 80-11.010(11)(C)6].

"6. Response to statistical analysis.

- A. *If the comparison for the upgradient wells shows a statistically significant increase (or pH change) over background, the owner/operator shall submit this information to the department.*
- B. *If the comparisons for downgradient wells show a statistically significant increase (or pH change), resulting from the landfill, over background, the owner/operator shall within ninety (90) days of the last sampling event obtain additional groundwater samples from those downgradient wells where a statistically significant difference was detected, split the samples in two (2), and obtain analyses of all additional samples to determine whether the significant statistical difference was a result of laboratory error.*
- C. *If the additional samples show a statistically significant increase (or pH change) over background, the owner/operator must demonstrate to the department within ninety (90) days that a source other than the utility waste landfill caused the contamination or that the statistically significant increase resulted from an error in sampling, analysis, statistical evaluation or natural variation. If the owner/operator cannot make this demonstration to the department, the owner/operator shall submit a plan to the department for a groundwater assessment monitoring program and implement the program as described in subparagraphs (11)(C)6.D. through H. of this rule. The plan shall specify the following:*
 - (I) *The number, location and depth of wells;*
 - (II) *Sampling and analytical methods for the monitoring parameters listed in Appendix I of this rule on a quarterly basis;*
 - (III) *Evaluation procedures, including any use of previously gathered groundwater quality information;*
 - (IV) *The rate and extent of migration of the contaminant plume in the groundwater; and*
 - (V) *The concentrations of the contaminant plume in the groundwater.*
- D. *After obtaining the results from the initial or subsequent sampling events required in subparagraph (11)(C)6.B. the owner/operator shall -*
 - (I) *Within fourteen (14) days, notify the department and place a notice in the operating record identifying the constituents that have been detected;*

- (II) Within ninety (90) days, and on a quarterly basis after that, resample all wells and conduct analysis for all constituents listed in Appendix I to this rule and notify the department of the constituent concentrations. A minimum of one (1) sample from each well sampled (background and downgradient) shall be collected and analyzed during these sampling events;
 - (III) Establish background concentrations for any new constituents detected during subsequent monitoring events; and
 - (IV) Establish groundwater protection standards for all new constituents detected during subsequent monitoring events.
- E. If the concentration of all constituents listed in Appendix I to this rule are shown to be at or below background levels as established in paragraph (11)(C)3. of this rule for two (2) consecutive sampling periods, the owner/operator may reinstate detection monitoring at the utility waste landfill as specified under subparagraph (11)(C)3.C. of this rule.
 - F. If the concentrations of any constituents listed in Appendix I of this rule are above background values, but all concentrations are below the groundwater protection standard established under subparagraph (11)(C)6.D. of this rule using the statistical procedures in paragraph (11)(C)5. of this rule, the owner/operator shall notify the department and the department may require the owner/operator to--
 - (I) Continue assessment monitoring; or
 - (II) Develop a corrective measures assessment, or both.
 - G. If one (1) or more constituents listed in Appendix I of this rule are detected at levels above the groundwater protection standard as established under subparagraph (11)(C)6.D., the owner/operator shall--
 - (I) Provide the department with a report assessing potential corrective measures;
 - (II) Characterize the nature and extent of the release by installing additional monitoring wells as necessary; install at least one (1) additional monitoring well at the facility boundary in the direction of contaminant migration and sample this well in accordance with paragraph (11)(C)6. of this rule and, if required by the department, notify all persons who own the land or reside on the land that directly overlies any part of the plume of contamination if contaminants have migrated off-site if indicated by sampling of wells; and
 - (III) Continue assessment monitoring as per the groundwater quality assessment plan, and implement the approved corrective action program specified in part (11)(C)6.G.(I) of this rule.
 - H. The results of implementation of the assessment monitoring program shall be submitted to the department at the end of each year or an alternate time period approved by the department."

Prior to implementing a response to a future SSI, it is recommended that the Missouri Code of State Regulations be reviewed to determine if the Solid Waste Management Rules regarding Response to Statistical Analysis have been revised.

11.9 Current MDNR Protocols

The following protocols are currently used by MDNR's Solid Waste Management Program in managing groundwater monitoring data for solid waste disposal areas and in evaluating that data for statistically significant increases (SSI's)

The SWMP has previously not allowed a verified SSI or its verification resample value(s) to be excluded as outliers from the database for control charts if the previously specified resample strategy shows that only the "future measurements" plot, including resample(s) measurement(s), does not exceed the "SCL - limit" line.

- Re-sampling SSI's must be conducted a minimum of one quarter later from the previous sampling event. MDNR's in-house laboratory or subcontractor will be given the option to split samples for each re-sampling event.
- If a subset of background data is to be excluded, or if a previous excluded subset of background data is to be re-included for statistical analysis, a request for modification to the approved statistical analysis plan must be submitted to and approved by the SWMP before implementation. This requirement does not include the data that would be temporarily excluded because of outlier testing during a single statistical analysis event.
- See Appendix 8, Attachment 1 for a flow diagram for implementing Prediction Intervals.
- See Appendix 8, Attachment 2 for a flow diagram for Non-Parametric Prediction Intervals for data that is non-normal or for data that cannot be normalized.

Prior to utilizing various MDNR protocols for statistical analysis of groundwater monitoring data, it is recommended that the SWMP be contacted to obtain updated recommendations on current protocols and/or policies.

12.0 REFERENCES


- Ameren Missouri Labadie Energy Center, Construction Permit Application for Utility Waste Landfill, prepared by Reitz & Jens, Inc. and GREDELL Engineering Resources, Inc.
- American Society of Testing and Materials (ASTM), 2007, *Standard Guide for Sampling Groundwater Monitoring Wells*: D 4448-01.
- American Society of Testing and Materials (ASTM), 2002, *Standard Practice for Low-Flow Purgung and Sampling for Wells and Devices Used for Ground-Water Quality Investigations*: D 6771-02.
- Detailed Site Investigation Report for Ameren Missouri Labadie Energy Center Proposed Utility Waste Disposal Area, Franklin County, Missouri, dated February 4, 2011, revised March 30, 2011 by GREDELL Engineering Resources, Inc. and Reitz & Jens, Inc.
- Gibbons, R. D.: 1994, *Statistical Methods for Groundwater Monitoring*, John Wiley & Sons, New York.
- Gilbert, R. O., 1987, Statistical Methods for Environmental Pollution Monitoring: Van Nostrand Reinhold, New York.
- Nielson, D.M., 1991, Practical Handbook of Groundwater Monitoring, Lewis Publishers, p.449-588.
- State of Missouri Solid Waste Management Regulations, 10 CSR 80-11.010 (effective August 30, 1998).
- State of Missouri Solid Waste Management Program, "Solid Waste Management Program, Statistical Analysis Plan Guidance", draft 4/26/2001.
- Tukey, J.W., 1977, Exploratory Data Analysis: Addison-Wesley.
- U.S. Environmental Protection Agency, November 1993, *Solid Waste Disposal Facility Criteria Technical Manual*: EPA/530-R-93-017, NTIC #PB94-100-450, Office of Solid Waste and Emergency Response, Washington, D.C.
- U.S. Environmental Protection Agency, 1992, *RCRA Groundwater Monitoring: Draft Technical Guidance*: EPA/530-R-93-001, NTIC # PB93-139-350, Office of Solid Waste and Emergency Response, Washington, D.C.
- U.S. Environmental Protection Agency, 2002, *Ground-Water Sampling Guidelines for Superfund and RCRA Project Managers*: EPA 542-S-02-001, Office of Solid Waste and Emergency Response, Washington, D.C.
- U.S. Environmental Protection Agency, May 2002, *Low-flow (Minimal Drawdown) Ground-water Sampling Procedures*: EPA/540/S-95/504, Office of Solid Waste and Emergency Response, Washington, D.C.

- U.S. Environmental Protection Agency, March 2009, *Statistical Analysis of Groundwater Monitoring Data at RCRA Facilities Unified Guidance*: EPA 530/R-09-007, Office of Resource Conservation and Recovery, Program Implementation and Information Division, Washington, D.C.
- U.S. Environmental Protection Agency, 1991b, *Handbook - Groundwater, Volume II: Methodology*. EPA/625/6-90/0166.
- U.S. Environmental Protection Agency, November 1986, *Test Methods for Evaluating Solid Waste - Physical/Chemical Methods, Third Edition (Revised)*, SW-846. Office of Solid Waste and Emergency Response, Washington, D.C.
- U.S. Environmental Protection Agency, 1986, *RCRA Groundwater Monitoring Technical Enforcement Guidance Document*: OSWER - 99550.1, Office of Waste Programs Enforcement, Office of Solid Waste and Emergency Response, Washington, D.C.

Figures

Revised November 2013

REVISIONS				
ZONE	REV	DESCRIPTION	DATE	APPROVED



THE ENGINEER WHOSE SIGNATURE AND PERSONAL SEAL APPEAR HEREON ASSUMES RESPONSIBILITY ONLY FOR WHAT APPEARS ON THIS PAGE AND DISCLAIMS PURSUANT TO SECTION 327.411 RSMO ANY RESPONSIBILITY FOR ALL OTHER PLANS, SPECIFICATIONS, ESTIMATES, REPORTS OR OTHER DOCUMENTS OR INSTRUMENTS NOT SEALED BY THE UNDERSIGNED ENGINEER RELATING TO OR INTENDED TO BE USED FOR ANY PART OR PARTS OF THE PROJECT TO WHICH THIS PAGE REFERS.

Reitz & Jens, Inc.
CONSULTING ENGINEERS
1055 CORPORATE SQUARE DRIVE
ST. LOUIS, MISSOURI 63132
314.993.4132 (voice) 314.993.4177 (fax)

GREDELL Engineering Resources, Inc.
ENVIRONMENTAL ENGINEERS
1000 Park High Street
Jefferson City, Missouri 65101
Telephone 573-639-3278
Facsimile 573-639-3279

PREPARED FOR





FIGURE 1, APPENDIX Q
LABADIE ENERGY CENTER
PROPOSED UTILITY WASTE LANDFILL
SITE LOCATION MAP

DRAWN W.J.A. (G.E.R.)	LOCATION 001009	LABADIE ENERGY CENTER	CLASS 02010
CHK'D R.L.R. (G.E.R.)			
SUP'D T.R.G. (G.E.R.)			
APPD. T.R.G. (G.E.R.)			REV.



ST. LOUIS,
MISSOURI





THE ENGINEER WHOSE SIGNATURE AND PERSONAL SEAL APPEAR HEREON ASSUMES RESPONSIBILITY ONLY FOR WHAT APPEARS ON THIS PAGE AND DISCLAIMS PURSUANT TO SECTION 327.411 RSMO ANY RESPONSIBILITY FOR ALL OTHER PLANS, SPECIFICATIONS, ESTIMATES, REPORTS OR OTHER DOCUMENTS OR INSTRUMENTS NOT SEALED BY THE UNDERSIGNED ENGINEER RELATING TO OR INTENDED TO BE USED FOR ANY PART OR PARTS OF THE PROJECT TO WHICH THIS PAGE REFERS.

REITZ & JENS, INC.
CONSULTING ENGINEERS
1050 CORPORATE SQUARE DRIVE
ST. LOUIS, MISSOURI 63132
314.653.4132 (voice) 314.653.4177 (fax)

GREDELL Engineering Resources, Inc.
ENVIRONMENTAL ENGINEERING
LAND USE ADVICE WATER
1050 East High Street, Jefferson City, Missouri 65101 Telephone 573-639-9678
Facsimile 573-639-9679

PREPARED FOR



FIGURE 3, APPENDIX Q
PROPOSED UTILITY WASTE LANDFILL
TYPICAL GROUNDWATER MONITORING
WELL CONSTRUCTION DETAIL

DRAWN A.I.K. (G.E.R.)	LOCATION 001009	LABADIE ENERGY CENTER	CLASS 02010
CHKD. M.C.C. (G.E.R.)			
SUPV. M.C.C. (G.E.R.)			
APPD. T.R.G. (G.E.R.)			



ST. LOUIS,
MISSOURI

DECEMBER 18, 2012

REV.

Tables

Revised November 2013

Construction Permit Application
Proposed Utility Waste Landfill
Ameren Missouri Labadie Energy Center
Franklin County, Missouri

Groundwater Sampling and Analysis Plan
Groundwater Monitoring Well Summary

Table 1

Monitoring Well Designation	Upgradient or Downgradient	Northing	Easting	Ground Surface Elevation (approx.)	Well Depth (feet, bgs)	Screen Length (feet)	Top of Screen Interval Elevation (approx.)
MW-1	DG	995574	727216	470	25	10	455
MW-2	DG	995656	727662	469	23	10	456
MW-3	DG	995738	728106	468	22	10	456
MW-4	DG	995819	728547	468	21	10	457
MW-5	DG	995548	728812	468	21	10	457
MW-6	DG	995171	729206	467	20	10	457
MW-7	DG	994600	729389	467	19	10	458
MW-8	DG	994380	729642	466	18	10	458
MW-9	DG	994160	729895	465	17	10	458
MW-10	DG	993940	730147	466	18	10	458
MW-11	DG	993720	730400	466	18	10	458
MW-12	DG	993500	730653	465	17	10	458
MW-13	DG	993280	730905	465	17	10	458
MW-14	DG	993060	731158	464	16	10	458
MW-15	DG	992840	731410	464	15	10	459
MW-16	DG	992620	731663	464	15	10	459
MW-17	DG	992302	731681	465	16	10	459
MW-18	DG	991674	730925	462	13	10	459
MW-19	DG	992096	730184	463	15	10	458
MW-20	DG	991668	729958	463	14	10	459
MW-21	DG	991332	729953	463	14	10	459
MW-22	UG	990940	729361	464	15	10	459
MW-23	UG	991102	728514	465	17	10	458
MW-24	UG	991822	727995	465	17	10	458
MW-25	UG	992708	727524	466	18	10	458
MW-26	UG	993986	726913	467	20	10	457
MW-27	UG	994619	726637	468	22	10	456
MW-28	UG	995267	726640	469	24	10	455
MW-29	DG	995679	726962	470	24	10	455
MW-30	DG	995760	727409	469	24	10	455
MW-31	DG	995836	727854	469	22	10	456
MW-32	DG	995914	728306	468	22	10	456
MW-33(D)	DG	995750	727359	469	75 to 85	10	384 to 394
MW-34(D)	DG	995544	728880	468	75 to 85	10	383 to 393
MW-35(D)	UG	992613	727529	466	75 to 85	10	381 to 391
TMW-1	DG	993795	728659	467	19	10	458

NOTES:

1. Refer to Figure 2 for proposed monitoring well locations.
2. MW-33(D), MW-34(D), and MW-35(D) are deep wells. Total depths are estimated.
3. TMW-1 is a temporary ("sentry") well located immediately east of initial cell construction area (Cell 1).
4. Basis for permanent well locations described in "Documentation of Groundwater Monitoring Well Design"; see Appendix X of Construction Permit Application.
5. Refer to Figure 3 for typical well construction details.
6. MW-1 through MW-21, MW-33(D), MW-34(D) and TMW-1, denote generally downgradient well positions. MW-22 through MW-28, and MW-35(D), denote generally upgradient well positions.

**Construction Permit Application
Proposed Utility Waste Landfill
Ameren Missouri Labadie Energy Center
Franklin County, Missouri**

**Groundwater Sampling and Analysis Plan
Groundwater Monitoring Schedule
Table 2**

Time	Item to Be Completed	Reports to MDNR
27 or 28 months before initial UWL operation	Install and develop groundwater monitoring wells.	Monitoring well installation records to Wellhead Protection Program
26 months before initial UWL operation	Initial sampling event	Initial groundwater field sampling and laboratory data to Solid Waste Management Program (SWMP)
23 months before initial UWL operation	Second sampling event	Groundwater field sampling and laboratory data to SWMP
20 months before initial UWL operation	Third sampling event	Groundwater field sampling and laboratory data to SWMP
17 months before initial UWL operation	Fourth sampling event	Groundwater field sampling and laboratory data to SWMP
14 months before initial UWL operation	Fifth round of sampling	Groundwater field sampling and laboratory data to SWMP
11 months before initial UWL operation	Sixth round of sampling	Groundwater field sampling and laboratory data to SWMP
8 months before initial UWL operation	Seventh round of sampling	Groundwater field sampling and laboratory data to SWMP
5 months before initial UWL operation	Eighth round of sampling	Report on field sampling and analytical data distributions and choice of intra-well or inter-well statistics to SWMP. Includes groundwater sampling data.
2 months before initial UWL operation	Submit Request for Operating Permit to MDNR	MDNR-SWMP has 60 days to review the submittal and make a decision on the Operating Permit.
Initial UWL operations begin.	N/A	N/A
Continue monitoring once per six months during May and November	Semi-annual sampling for routine detection monitoring	Groundwater field sampling, laboratory data and statistical report within 90 days of each subsequent sampling event to SWMP

Appendices

Appendix 1

Driller's Logs and Monitoring Well Construction Details

This Appendix Intentionally Left Blank.
Information to be included following installation
of groundwater monitoring wells.

Appendix 2

Missouri Solid Waste Management Rule
Constituents for Detection Monitoring
(10 CSR 80-11.010, Appendix I)
Revised August 2013

**Ameren Missouri Labadie Energy Center
Groundwater Sampling and Analysis Plan**

**Constituents for Detection Monitoring
10 CSR 80-11.010 (Appendix I)**

Chemical Constituent	Units	Method ¹	PQL ²
Aluminum (Al)	ug/l	6010B	50
Antimony (Sb)	ug/l	7010	5
Arsenic (As)	ug/l	7010	3
Barium (Ba)	ug/l	6010B	5
Beryllium (Be)	mg/l	6010B	0.001
Boron (B)	ug/l	6010B	20
Cadmium (Cd)	ug/l	6010B	2
Calcium (Ca)	mg/l	6010B	0.05
Chemical Oxygen Demand (COD)	mg/l	410.4	10
Chloride	mg/l	9251	5
Chromium (Cr)	ug/l	6010B	10
Cobalt (Co)	ug/l	6010B	10
Copper (Cu)	ug/l	6010B	10
Fluoride	mg/l	9214	0.10
Hardness	mg/l	2340B	NA
Iron (Fe)	ug/l	6010B	20
Lead (Pb)	ug/l	7010	2
Magnesium (Mg)	mg/l	6010B	0.01
Manganese (Mn)	ug/l	6010B	5
Mercury (Hg)	ug/l	7470A	0.2
Molybdenum (Mo) ³	ug/l	6010B	10
Nickel (Ni)	mg/l	6010B	0.01
pH (Field)	S.U.	NA	NA
Selenium (Se)	ug/l	6010B	30
Silver (Ag)	ug/l	6010B	10
Sodium (Na)	mg/l	6010B	0.05
Specific Conductance (Field)	umhos/cm	NA	NA
Sulfate	mg/l	9036	10
Thallium (Tl)	ug/l	7010	2
Total Dissolved Solids (TDS)	mg/l	2540C	20
Total Organic Carbon (TOC)	mg/l	9060	1
Total Organic Halogens (TOX)	mg/l	9020B	0.02
Zinc (Zn)	ug/l	6010B	10
Ground Water Elevation (Field)	feet	NA	NA

1. Suggested Methods refer to analytical procedure numbers used in EPA Report SW-846 "Test Methods for Evaluating Solid Waste", third edition, November 1986, as revised, December 1987, or applicable updates.
2. Practical Quantitation Limits as established by the contract laboratory.
3. Molybdenum added per the request of MDNR-SWMP in correspondence dated March 7, 2013 and May 7, 2013.

Appendix 3

Field Equipment Calibration Forms and Procedures

Field Instrumentation Calibration Log

Calibrated by: _____

Field Instrument: _____

S/N #: _____

	Date	Time	pH Standards	pH Measurements	Specific Conductivity Standard ($\mu\text{s}/\text{cm}$)	Specific Conductivity Measurement ($\mu\text{s}/\text{cm}$)	Oxidation Reduction Potential Standard (mV)	Oxidation Reduction Potential Measurement (mV)	Turbidity Standards (NTU)	Turbidity Measurements (NTU)
Beginning of Day Calibration			4.00	=	1413	=	Temperature (°C)	=	0.02	=
			7.00	=				=		=
			10.00	=				=		=
End of Day Check			4.00	=	1413	=	Standard (mV)	=	0.02	=
			7.00	=				=		=
			10.00	=				=		=

Notes:

I certify that the aforementioned meters were calibrated within the manufacturer's specifications.

Date: _____ By: _____

ORP Interpolation Reference Table

Temperature °C	ORP mV												
0.0	237.0	6.6	231.4	13.2	228.1	19.7	223.2	26.3	219.0	32.7	214.4	39.3	209.6
0.1	236.9	6.7	231.3	13.3	228.0	19.8	223.2	26.4	218.9	32.8	214.3	39.4	209.5
0.2	236.8	6.8	231.3	13.4	228.0	19.9	223.1	26.5	218.8	32.9	214.3	39.5	209.4
0.3	236.7	6.9	231.2	13.4	228.0	20.0	223.0	26.6	218.7	33.0	214.2	39.6	209.3
0.4	236.6	7.0	231.2	13.5	227.9	20.1	222.9	26.7	218.6	33.1	214.1	39.7	209.2
0.5	236.5	7.1	231.2	13.6	227.8	20.2	222.9	26.8	218.6	33.2	214.1	39.8	209.2
0.6	236.4	7.2	231.1	13.7	227.8	20.3	222.8	26.9	218.5	33.3	214.0	39.9	209.1
0.7	236.3	7.3	231.1	13.8	227.7	20.4	222.8	27.0	218.4	33.4	214.0	40.0	209.0
0.8	236.2	7.4	231.0	13.9	227.7	20.5	222.7	27.1	218.3	33.5	213.9	40.1	208.9
0.9	236.1	7.5	231.0	14.0	227.6	20.6	222.6	27.2	218.2	33.6	213.8	40.2	208.8
1.0	236.0	7.6	231.0	14.1	227.5	20.7	222.6	27.3	218.2	33.7	213.8	40.3	208.8
1.1	235.9	7.7	230.9	14.2	227.5	20.8	222.5	27.4	218.1	33.8	213.7	40.4	208.7
1.2	235.8	7.8	230.9	14.3	227.4	20.9	222.5	27.5	218.0	33.9	213.7	40.5	208.6
1.3	235.7	7.9	230.8	14.4	227.4	21.0	222.4	27.6	217.9	34.0	213.6	40.6	208.5
1.4	235.6	8.0	230.8	14.5	227.3	21.1	222.3	27.7	217.8	34.1	213.5	40.7	208.4
1.5	235.5	8.1	230.8	14.6	227.2	21.2	222.3	27.8	217.8	34.2	213.5	40.8	208.4
1.6	235.4	8.2	230.7	14.7	227.2	21.3	222.2	27.9	217.7	34.3	213.4	40.9	208.3
1.7	235.3	8.3	230.7	14.8	227.1	21.4	222.2	28.0	217.6	34.4	213.4	41.0	208.2
1.8	235.2	8.4	230.6	14.9	227.1	21.5	222.1	28.1	217.5	34.5	213.3	41.1	208.1
1.9	235.1	8.5	230.6	15.0	227.0	21.6	222.0	28.2	217.4	34.6	213.2	41.2	208.0
2.0	235.0	8.6	230.6	15.1	226.9	21.7	222.0	28.3	217.4	34.7	213.2	41.3	208.0
2.1	234.9	8.7	230.5	15.2	226.8	21.8	221.9	28.4	217.3	34.8	213.1	41.4	207.9
2.2	234.8	8.8	230.5	15.3	226.8	21.9	221.9	28.5	217.2	34.9	213.1	41.5	207.8
2.3	234.7	8.9	230.4	15.4	226.7	22.0	221.8	28.6	217.1	35.0	213.0	41.6	207.7
2.4	234.6	9.0	230.4	15.5	226.6	22.1	221.7	28.7	217.0	35.1	212.9	41.7	207.6
2.5	234.5	9.1	230.4	15.6	226.5	22.2	221.7	28.8	217.0	35.2	212.8	41.8	207.6
2.6	234.4	9.2	230.3	15.7	226.4	22.3	221.6	28.9	216.9	35.3	212.8	41.9	207.5
2.7	234.3	9.3	230.3	15.8	226.4	22.4	221.6	29.0	216.8	35.4	212.7	42.0	207.4
2.8	234.2	9.4	230.2	15.9	226.3	22.5	221.5	29.1	216.7	35.5	212.6	42.1	207.3
2.9	234.1	9.5	230.2	16.0	226.2	22.6	221.4	29.2	216.6	35.6	212.5	42.2	207.2
3.0	234.0	9.6	230.2	16.1	226.1	22.7	221.4	29.3	216.6	35.7	212.4	42.3	207.2
3.1	233.9	9.7	230.1	16.2	226.0	22.8	221.3	29.4	216.5	35.8	212.4	42.4	207.1
3.2	233.8	9.8	230.1	16.3	226.0	22.9	221.3	29.3	216.6	35.9	212.3	42.5	207.0
3.3	233.7	9.9	230.0	16.4	225.9	23.0	221.2	29.4	216.5	36.0	212.2	42.6	206.9
3.4	233.6	10.0	230.0	16.5	225.8	23.1	221.1	29.5	216.4	36.1	212.1	42.7	206.8
3.5	233.5	10.1	229.9	16.6	225.7	23.2	221.1	29.6	216.3	36.2	212.0	42.8	206.8
3.6	233.4	10.2	229.9	16.7	225.6	23.3	221.0	29.7	216.2	36.3	212.0	42.9	206.7
3.7	233.3	10.3	229.8	16.8	225.6	23.4	221.0	29.8	216.2	36.4	211.9	43.0	206.6
3.8	233.2	10.4	229.8	16.9	225.5	23.5	220.9	29.9	216.1	36.5	211.8	43.1	206.5
3.9	233.1	10.5	229.7	17.0	225.4	23.6	220.8	30.0	216.0	36.6	211.7	43.2	206.4
4.0	233.0	10.6	229.6	17.1	225.3	23.7	220.8	30.1	215.9	36.7	211.6	43.3	206.4
4.1	232.9	10.7	229.6	17.2	225.2	23.8	220.7	30.2	215.9	36.8	211.6	43.4	206.3
4.2	232.8	10.8	229.5	17.3	225.2	23.9	220.7	30.3	215.8	36.9	211.5	43.5	206.2
4.3	232.7	10.9	229.5	17.4	225.1	24.0	220.6	30.4	215.8	37.0	211.4	43.6	206.1
4.4	232.6	11.0	229.4	17.5	225.0	24.1	220.5	30.5	215.7	37.1	211.3	43.7	206.0
4.5	232.5	11.1	229.3	17.6	224.9	24.2	220.5	30.6	215.6	37.2	211.2	43.8	206.0
4.6	232.4	11.2	229.3	17.7	224.8	24.3	220.4	30.7	215.6	37.3	211.2	43.9	205.9
4.7	232.3	11.3	229.2	17.8	224.8	24.4	220.4	30.8	215.5	37.4	211.1	44.0	205.8
4.8	232.2	11.4	229.2	17.9	224.7	24.5	220.3	30.9	215.5	37.5	211.0	44.1	205.7
4.9	232.1	11.5	229.1	18.0	224.6	24.6	220.2	31.0	215.4	37.6	210.9	44.2	205.6
5.0	232.0	11.6	229.0	18.1	224.5	24.7	220.2	31.1	215.3	37.7	210.8	44.3	205.6
5.1	232.0	11.7	229.0	18.2	224.4	24.8	220.1	31.2	215.3	37.8	210.8	44.4	205.5
5.2	231.9	11.8	228.9	18.3	224.4	24.9	220.1	31.3	215.2	37.9	210.7	44.5	205.4
5.3	231.9	11.9	228.9	18.4	224.3	25.0	220.0	31.4	215.2	38.0	210.6	44.6	205.3
5.4	231.8	12.0	228.8	18.5	224.2	25.1	219.9	31.5	215.1	38.1	210.5	44.7	205.2
5.5	231.8	12.1	228.7	18.6	224.1	25.2	219.8	31.6	215.0	38.2	210.4	44.8	205.2
5.6	231.8	12.2	228.7	18.7	224.0	25.3	219.8	31.7	215.0	38.3	210.4	44.9	205.1
5.7	231.7	12.3	228.6	18.8	224.0	25.4	219.7	31.8	214.9	38.4	210.3	45.0	205.0
5.8	231.7	12.4	228.6	18.9	223.9	25.5	219.6	31.9	214.9	38.5	210.2		
5.9	231.6	12.5	228.5	19.0	223.8	25.6	219.5	32.0	214.8	38.6	210.1		
6.0	231.6	12.6	228.4	19.1	223.7	25.7	219.4	32.1	214.7	38.7	210.0		
6.1	231.6	12.7	228.4	19.2	223.6	25.8	219.4	32.2	214.7	38.8	210.0		
6.2	231.5	12.8	228.3	19.3	223.6	25.9	219.3	32.3	214.6	38.9	209.9		
6.3	231.5	12.9	228.3	19.4	223.5	26.0	219.2	32.4	214.6	39.0	209.8		
6.4	231.4	13.0	228.2	19.5	223.4	26.1	219.1	32.5	214.5	39.1	209.7		
6.5	231.4	13.1	228.1	19.6	223.3	26.2	219.0	32.6	214.4	39.2	209.6		

Note: Standard ORP measurements 0, 5, 10, 15, 20, 25, 30, 35, and 40 were provided by Geotech Environmental Equipment, Inc.
The rest of the standard ORP measurements were interpolated from Geotech Standard ORP measurements.

FIELD EQUIPMENT CALIBRATION PROCEDURES

Multi-meter pH, Temperature, Conductivity, Oxidation Reduction Potential (ORP)

pH Calibration/Operation Procedures

(Reference EPA Method 9040)

The field pH meter will be calibrated each day water samples are collected. Calibration results will be recorded on the Field Instrumentation Calibration Log in Appendix 3 of the Sampling and Analysis Plan.

pH Three-Buffer Calibration

This procedure is recommended for precise measurements.

1. Select three buffers which bracket the expected sample pH. The first should be near the electrode isopotential point (pH 7) and the second and third should bracket the expected sample pH (e.g. pH 4 and pH 10).
2. Rinse electrode first with distilled water and then with pH 7 buffer. Place the electrode in pH 7 buffer.
3. Wait for stable display. Set the meter to the pH value of the buffer at its measured temperature. (ATC @ 25°C = 7.00).
4. Rinse electrode first with distilled water and then with the second buffer. Place the electrode in the second buffer.
5. When the display is stable, set the meter to the actual pH value of the buffer as described in the meter instruction manual.
6. Rinse electrode first with distilled water and then with the third buffer. Place the electrode in the third buffer.
7. When the display is stable, set the meter to the actual pH value of the buffer as described in the meter instruction manual.
8. If all steps are performed correctly, and the slope is between 92 and 102%, proceed to pH Measurement.

For detailed calibration and temperature compensation procedures, consult meter instruction manual.

pH Measurement

1. Obtain a neat sample from collection device and place electrode directly into sample.
2. Allow reading to stabilize.
3. Record pH reading directly from meter and record on the Field Sampling Log.
4. Probes are to be decontaminated by multiple rinses with distilled water.

FIELD EQUIPMENT CALIBRATION PROCEDURES

If the above procedures do not work, refer to Troubleshooting section of instrument instruction manual.

Measuring Hints

1. Always use fresh buffers for calibration. Choose buffers that are no more than 3 pH units apart.
2. Check electrode slope daily by performing a three-buffer calibration. Slope should be 92 to 102%.
3. Between measurements, rinse electrodes with distilled water and then with the next solution to be measured.
4. Stir all buffers and samples.
5. Avoid rubbing or wiping electrode bulb, to reduce chance of error due to polarization.

Interferences

Oil samples and salty samples may leave residues on the electrodes. The probe has to be rinsed thoroughly between all measurements using distilled water to remove salt residues. If oily residues need to be removed, rinse with acetone then distilled water. The electrodes need to be kept wet to ensure proper response.

FIELD EQUIPMENT CALIBRATION PROCEDURES

Conductivity/Temperature Calibration/

Operation Procedures

(Reference EPA Method 9050)

Calibration Procedures

Conductivity will be checked at a minimum of once per day using commercial traceable standards in the 1000 and 10,000 mmhos/cm range and recorded on the Field Instrumentation Calibration Log. Calibration checks outside of a \pm 10% range are not acceptable and will require the sensor replacement and/or re-check of the standards. If calibration check standards are still outside \pm 10% range, use alternate meter. Do not proceed with sample collection without acceptable calibration checks.

Temperature measurement is factory calibrated. Temperature will be checked for calibration by comparison with a laboratory thermometer within a \pm 10% range prior to the sample event.

Temperature Measurement

Report all values on the Field Sampling Log in degrees Celsius ($^{\circ}$ C).

1. Immerse the temperature/conductivity sensor into the sample.
2. Record temperature reading directly from meter and record on the Field Sampling Log.

Conductivity Measurement

Report all values on the Field Sampling Log in umhos/cm (μ S/cm).

1. Immerse the temperature/conductivity sensor into the sample.
2. Record conductivity reading directly from meter and record on the Field Sampling Log.
3. Sensors are to be decontaminated by multiple rinses with distilled water.

Most meters have a fixed temperature coefficient (TC) of 2.1% per $^{\circ}$ C and a fixed reference temperature of 25 $^{\circ}$ C. These parameters are sufficient for the majority of "natural water" samples.

FIELD EQUIPMENT CALIBRATION PROCEDURES

Oxidation Reduction Potential (ORP) Calibration/

Operation Procedures

(Reference YSI Environmental)

ORP Calibration

Report all values on the Field Instrumentation Calibration Log in millivolts (mV).

1. Select ORP.
2. Immerse the sensor into the calibration solution.
3. Use the keypad to enter the correct value of the calibration solution you are using at the current temperature (Refer to the Appendix 3 ORP Interpolation Reference Table in the Sampling and Analysis Plan).
4. Record ORP reading directly from meter and record on the Field Instrumentation Calibration Log.
5. Sensors are to be decontaminated by multiple rinses with distilled water.

ORP Measurement

Report all values on the Field Sampling Log in millivolts (mV).

1. Select ORP.
2. Immerse the sensor into the sample.
3. Use the keypad to enter the correct value of the calibration solution you are using at the current temperature (Refer to the Appendix 3 ORP Interpolation Reference Table in the Sampling and Analysis Plan).
4. Record ORP reading directly from meter and record on the Field Sampling Log.
5. Sensors are to be decontaminated by multiple rinses with distilled water.

Low-Flow cell calibration

The manufacturer's recommended procedures shall be followed for low-flow cell calibration. A copy of these procedures is to be made a part of this sampling and analysis plan.

FIELD EQUIPMENT CALIBRATION PROCEDURES

Turbidimeter Calibration/ Operation Procedures (Reference HF Scientific)

The Turbidimeter allows for the measurement of turbidity in the field. The instrument measures and reports the turbidity of a sample in nephelometric turbidity units (NTU's).

Turbidimeter Calibration

The instrument was calibrated and tested prior to leaving the factory. The instrument requires three (3) standards to be calibrated.

1. Select the calibration function of the instrument by pressing the CAL button once. The "CAL" block will be illuminated on the display with "1" indicating the standard required for this step of the calibration. This is the first standard that should be used in a full calibration.
2. Insert the 1000 NTU standard (CAL 1 in the figure above) into the sample well and press down until the cuvette snaps fully into the instrument. Align the indexing ring with the arrow on the instrument.
3. Wait for the reading to stabilize. Once the reading has stabilized press the enter button to indicate to the instrument that it should calibrate on this point.
4. When the instrument has completed calibration on this point, it prompts you to insert the next calibration standard into the sample well (CAL 2).
5. Repeat steps 2-4 for each calibration standard. When you calibrate on CAL 3 (turbidity free water), the instrument will automatically exit out of calibration returning back to the normal operating mode.

Turbidimeter Measurement

Turn on the instrument by pressing the ON/OFF button continuously for 1 second. Allow 75-second warm-up period while preparing for the turbidity measurement as described in the following steps:

1. Sample approximately 100 ml of your process, as you would normally do for turbidity measurement.
2. Obtain a clean and dry sample cuvette.
3. Rinse the cuvette with approximately 10 ml of the sample water (2/3 of cuvette volume), capping the cuvette with the black light shield (cuvette top) and inverting several times. Discard the used sample and repeat the rinsing procedure two more times.
4. Completely fill the rinsed cuvette (from step 3) with the remaining portion (approximately 15 ml) of the grab sample and then cap the cuvette with the supplied cap. Ensure that the outside of the cuvette is dry, clean and free from smudges.

FIELD EQUIPMENT CALIBRATION PROCEDURES

5. Place the cuvette into the instrument and press it down until it snaps fully into the sample well. Index the cuvette by pressing and holding down the enter button while rotating the cuvette to identify the lowest reading (the displayed turbidity is continuously updated on the display). Once the cuvette is indexed, release the enter button to display the measured turbidity.

Appendix 4

Sample Container and Preservation Guidelines and Groundwater Sampling Bottle Inventory Form

Ameren Missouri LABADIE ENERGY CENTER
Groundwater Sampling and Analysis Plan

Sample Container and Preservation Guidelines

Measurement	Volume Req., (ml)	Container ^a	Preservative	Max. Holding Times	Reference
Specific Cond. (Field)	100	P, G	None	Det. on Site	1
pH (Field)	50	P, G	None	Det. on Site	1, 2
Temperature (Field)	1000	P,G	None	Det. on Site	1
Oxidation Reduction Potential	1000	P,G	None	Det. on Site	
Turbidity	1000	P,G	None	Det. on Site	
Inorganics, Non-Metallics					
Fluoride	300	P, G	HNO ₃ to pH <2	28	1, 2
Total Organic Carbon	100	G _b	Cool, 4°C; HCl or H ₂ SO ₄ to pH <2	28	1
Total Dissolved Solids	500	P, G	Cool, 4°C	7 Days	1,4
Chloride	500	P, G	Cool,4°C	28 Days	1, 2
Sulfate	200	P, G	Cool, 4°C	28 Days	1, 2,4
Total Organic Halides (TOX)	2000	G	Cool, 4°C; HCl or H ₂ SO ₄ to pH <2	7 Days	4
COD	50	P, G	H ₂ SO ₄ to pH <2	28 Days	1
Metals					
Total Recoverable	500	P, G	HNO ₃ to pH <2	6 Mos	1, 2
Mercury	500	P, G	HNO ₃ to pH <2	28 Days	1, 2

NOTES:

- a. Plastic (P) or Glass (G). For metals, polyethylene with an all polypropylene cap is preferred.
- b. Use Teflon® lined cap.
- c. Silver requires an amber bottle

REFERENCES:

1. Methods for Chemical Analysis of Water and Wastes, March, 1983, USEPA, 600/4-79-020 and additions thereto.
2. Test Methods for Evaluating Solid Waste, Physical/Chemical Method, November, 1986, Third Edition, USEPA, SW-846 and additions thereto.
3. Guidelines Establishing Test Procedures for the Analysis of Pollutant Under the Clean Water Act", Environmental Protection Agency, Code of Federal Regulations (CFR), Title 40, Part 136.
4. MDNR-FSS-001, Required/Recommended Containers, Volumes, Preservatives, Holding Times, and Special Sampling Considerations, Randy Crawford, Trish Rielly, Water Quality Monitoring Section, MDNR ESP September 17, 2003

Groundwater Sampling Bottle Inventory

Bottles delivered by: _____

H_2SO_4 = Sulfuric Acid

HNO_3 = Nitric Acid

Appendix 5

Monitoring Well Field Inspection Form

Monitoring Well Field Inspection

Facility: Ameren Missouri Labadie Energy Center Utility Waste Landfill
Monitoring Well ID: _____

Name (Field Sampler): _____

Date: _____

Access:

Accessibility: Good _____ Fair _____ Poor _____

Well clear of weeds and/or debris?: Yes _____ No _____

Well identification clearly visible?: Yes _____ No _____

Remarks:

Concrete Pad:

Condition of Concrete Pad: Good _____ Inadequate _____

Depressions or standing water around well?: Yes _____ No _____

Remarks:

Protective Outer Casing: Material =

Condition of Protective Casing: Good _____ Damaged _____

Condition of Locking Cap: Good _____ Damaged _____

Condition of Lock: Good _____ Damaged _____

Condition of Weep Hole: Good _____ Damaged _____

Remarks:

Well Riser: Material =

Condition of Riser: Good _____ Damaged _____

Condition of Riser Cap: Good _____ Damaged _____

Measurement Reference Point: Yes _____ No _____

Remarks:

Dedicated Purging/Sampling Device: Type -

Condition: Good _____ Damaged _____ Missing _____

Remarks:

Field Certification

Signed

Title

Date

Appendix 6

Field Sampling Log and Volume Tracking Log Forms

Field Sampling Log

Facility: Ameren Missouri Labadie Energy Center UWL

Date: _____ Monitoring Well ID: _____

Name (Field Sampler): _____

Gas Detected Y / N

PURGE INFORMATION:

Method of Well Purge: _____

Dedicated?

Y / N

Date/Time Initiated: _____

One (1) Well Volume (ml):

Initial Water Level (feet): _____

Total Volume Purged (ml):

GroundWater Elevation (NGVD): _____

Well Purged To Dryness?

Well Total Depth (feet): _____

Water Level after Purge (feet):

PURGE DATA:

Field Sampling Log

Sampling Information: Date: _____ Monitoring Well ID: _____

Method of Sampling: low flow, peristaltic pump

Dedicated: Y / N

Water Level @ Sampling, Feet: _____

Monitoring Event: Annual Semi-Annual Quarterly Monthly Other

Sampling Data:

Date/Time	Sample Rate ml/min	Temp (°C)	pH	Specific Conductivity (µS)	Oxidation Reduction Potential (mV)	Dissolved Oxygen (mg/L)	Turbidity (NTU)

Instrument Check Data:

pH Meter Serial #: 1* 4.0 std. = 1* 7.0 std. = 1* 10.0 std. 1*

Conduct. Meter Serial #: 1* standard = 1* µS reading = 1* µS

Turbidity Meter Serial #: 1* standard = 1* NTU reading = 1* NTU

* See instrument calibration log for daily calibration data.

General Information:

Weather Conditions @ time of sampling: _____

Sample Characteristics: _____

Sample Collection Order: Per SOP

Comments and Observations:

I certify that sampling procedures were in accordance with applicable EPA and State protocols.

Date: _____ By: _____ Title: _____

Volume Tracking Log

Facility Name: Ameren Missouri Labadie Energy Center UWL

Note: Each Tick mark is equal to 1000 mL or 1L.

Total volume based on a 1L graduated cylinder.

Appendix 7

Example Chain-of-Custody Field Record Form

Chain of Custody Record


Date: _____ Page: ____ of ____

Appendix 8

Decision Flow Charts



Ameren Missouri LABADIE Energy Center
Groundwater Sampling and Analysis Plan

**Selection of Statistical Procedure Based on Groundwater
Background Data**





Note 1: This logic step is complex and will consist of various other steps. Exact steps are to be determined after data is available.

Attachment 1: Prediction Interval Test Strategy



Source: Missouri Department of Natural Resources Solid Waste Management Program DRAFT Technical Bulletin: "Statistical Analysis Plan Guidance", 4/26/01.

Attachment 2: Control Chart & Non-Parametric Prediction Interval Test Strategy



Source: Missouri Department of Natural Resources Solid Waste Management Program DRAFT Technical Bulletin "Statistical Analysis Plan Guidance", 4/26/01.